

## About Desiccant / 乾燥剤について

### Use the supplied desiccant

The desiccant is supplied with the camera to prevent the lens from mist and condensation.

**Note:** Do not expose the desiccant to moisture and do not touch it with wet hands. Prevent water droplets from entering inside of the lens cover and camera when the lens is adjusted.

### How to use the desiccant

Perform the following after adjusting the image focus, etc.

1. Peel the protection seals off the desiccant.
2. Attach the desiccant onto the inner bottom of the lens cover along the guide ribs (refer to the illustration below) and re-attach the front cover to the camera as quickly as possible (within 5 minutes)

### 乾燥剤の使用について

レンズのくもりや結露を防ぐため、カメラに付属の乾燥剤を必ず使用してください。

<メモ> 乾燥剤を湿気にさらしたりぬれた手で触れたりしないでください。

レンズの調整時に、レンズカバー内部およびカメラ内部に水滴が入らないようにしてください。

### 乾燥剤の貼り付け方法

**注意：**画角や焦点などレンズの調節を終えてから行います。

1. 乾燥剤からシールをはがします。
2. 乾燥剤をレンズカバーの底面に、ガイドリブに沿って貼り付けた（イラスト参照）あとにできるだけ早く（5分以内に）前面カバーをカメラに取り付けてください。

